

Installation Instructions for All Oil Reservoirs

- 1. Locate the reservoir in a warm, draft-free area.
- 2. Install the reservoir in a vertical position between the separator and the oil level controls.
- 3. Clamp and support reservoir and piping properly to minimize vibration potential.
- 4. Be sure to not block view of oil sight glasses.
- 5. Install a pressure-reducing check valve from the oil reservoir vent port to suction line.
- 6. Keep reservoir cool when brazing.
- 7. Add the specific type of compressor oil being used, and fill to the bottom of the top sight glass.
- 8. Check oil level on new installations frequently.

Got a question? Call us at 1-800-552-9300 or check out our website at www.temprite.com