

Part description	Part #	ZX single fan	ZXL single fan	ZX dual fan	ZXL dual fan	ZXD single fan	ZXD dual fan
Bracket-Fan Motor	074-1425-00	X	X				
Bracket-Fan Motor	074-1424-00			X	X	X	X
Motor-Fan	050-0308-01	X	X	X	X	X	X
Blade-Fan	083-6931-00	X	X	X	X	X	X
Control-Low Pressure	085-0268-03	X		X		X	X
Sensor-Vapor Out	043-0201-00		X				
Sensor-Vapor In	043-0202-00		X				
Sensor-Vapor Out	043-0201-01				X		
Sensor-Vapor In	043-0202-01				X		
Fuse	071-0653-00	X	X	X	X	X	X
Hotkey without SW	085-0276-00	X	X	X	X	X	X
Power Cable-Molded Plug	529-0060-04	X	X	X			
Coil-EXV	023-0105-01	X	X		X		
Valve-EXV	010-0104-00	X	X	X	X		
Capacitor	014-0079-00	X	X	X			
Sensor-Coil	043-0199-00	X	X	X	X	X	X
Sensor-Ambient	043-0198-00	X	X	X	X	X	X
Thermistor-Discharge	043-0200-00	X	X				
Coil-EXV	023-0105-00			X			
Thermistor-Discharge	043-0200-01			X	X	X	X
Control-High Pressure	085-0267-02	X	X	X	X	X	X
Trensducer-Pressure	039-0044-01	X	X	X	X	X	X
Valve Body	010-0125-00					X	X
Coil-Holding	023-0088-00					X	X

Part description	Compressor Model #	ZX single fan	ZXL single fan	ZX dual fan	ZXL dual fan	ZXD single fan	ZXD dual fan
Compressor	ZX15KCE-PFJ-558	ZX020BE-PFJ-462					
Compressor	ZX21KCE-PFJ-558	ZX030BE-PFJ-462					
Compressor	ZX29KCE-PFJ-558	ZX040BE-PFJ-462					
Compressor	ZX15KCE-TFD-558	ZX020BE-TFD-462					
Compressor	ZX21KCE-TFD-558	ZX030BE-TFD-462					
Compressor	ZX30KCE-TFD-558	ZX040BE-TFD-462					
Compressor	ZX106KCE-PFJ-687		ZXL-020BE-PFJ-462				
Compressor	ZX109KCE-PFJ-687		ZXL-030BE-PFJ-462				
Compressor	ZX106KCE-TFD-687		ZXL-020BE-TFD-462				
Compressor	ZX109KCE-TFD-687		ZXL-030BE-TFD-462				
Compressor	ZX114KCE-TFD-647		ZXL-040BE-TFD-462				
Compressor	ZX38KCE-TFD-558			ZX050BE-TFD-462			
Compressor	ZX45KCE-TFD-558			ZX060BE-TFD-462			
Compressor	ZX51KCE-TFD-558			ZX076BE-TFD-462			
Compressor	ZX115KCE-TFD-557				ZXL-050BE-TFD-462		
Compressor	ZX118KCE-TFD-557				ZXL-060BE-TFD-462		
Compressor	ZX121KCE-TFD-557				ZXL-075BE-TFD-462		
Compressor	ZBD21KQE-TFD-558					ZXD030BE-TFD-462	
Compressor	ZBD29KQE-TFD-558						ZXD040BE-TFD-462
Compressor	ZBD38KQE-TFD-558						ZXD050BE-TFD-462
Compressor	ZBD45KQE-TFD-558						ZXD060BE-TFD-462
Compressor	ZBD48KQE-TFD-558						ZXD076BE-TFD-462

Part description	Part #	ZX single fan	ZXL single fan	ZX dual fan	ZXL dual fan	ZXD single fan	ZXD dual fan
Run Capacitor for comp. ZX15KCE-PFJ-558	014-0064-14	ZX020BE-PFJ-462					
Run Capacitor for comp. ZX21KCE-PFJ-558	014-0064-26	ZX030BE-PFJ-462					
Run Capacitor for comp. ZX29KCE-PFJ-558	014-0064-26	ZX040BE-PFJ-462					
Run Capacitor for comp. ZX106KCE-PFJ-687	014-0064-27		ZXL-020BE-PFJ-462				
Run Capacitor for comp. ZX109KCE-PFJ-687	014-0064-27		ZXL-030BE-PFJ-462				

Part description	Part #	UNIT
Controller + 3 hotkeys service kit	991-0300-01	ZX, ZXL, ZXD
Controller-Unit With SW	543-0225-18	ZX
Controller-Unit With SW	543-0225-19	ZXL
Controller-Unit With SW	543-0225-20	ZXD