




INDOOR R32 U-MATCH CASSETTES

SPARE PARTS LIST

February 2023

GUD50T/B-S

Exploded View




GUD50T/B-S

Spare Parts List

No.	Part Description	Part Code
1	Electric Box Assy	100002061280
2	Terminal Board	42018000551
3	Diversion Circle	26909400067
4	Water Tray Assy	000069060008
5	Centrifugal Fan	10429400004
6	Liquid Level Switch	4502021601
7	Body Installing Plate	01332701
8	Seal plate Assy	01499400003
9	Fixed Mount(Evaporator)	0184940002001P
10	Evaporator Assy	01100106092901
11	Side Plate 1	01319400049
12	Side Plate 3	01319400051
13	Side Plate 2	01319400050
14	Base Plate Sub-Assy	02229400011
15	Strainer	0721200102
16	Support	01809400052
17	Brushless DC Motor	1570410000702
18	Water Pump	43138000058
19	Drainage Pipe Sub-Assy	26909400055
20	Remote Control	N/A
21	Temperature Sensor	390000453
22	Tube sensor	39000286
23	Drain Hose Sub-Assy	05232702
24	Terminal board	42000100000202
25	Filter Board	30221000021
26	Main Board	300002060224

GUD71T/B-S

Exploded View




GUD71T/B-S

Spare Parts List

No.	Part Description	Part Code
1	Electric Box Assy	100002061280
2	Terminal Board	42018000551
3	Diversion Circle	26909400067
4	Water Tray Assy	000069060008
5	Centrifugal Fan	10429400004
6	Liquid Level Switch	4502021601
7	Body Installing Plate	01332701
8	Seal plate Assy	01499400003
9	Fixed Mount(Evaporator)	0184940002001P
10	Evaporator Assy	011001060929
11	Side Plate 1	01319400049
12	Side Plate 3	01319400051
13	Side Plate 2	01319400050
14	Base Plate Sub-Assy	02229400011
15	Strainer	0741520000201
16	Support	01809400052
17	Brushless DC Motor	1570410000702
18	Water Pump	43138000058
19	Drainage Pipe Sub-Assy	26909400055
20	Remote Control	N/A
21	Temperature Sensor	390000453
22	Tube sensor	39000286
23	Drain Hose Sub-Assy	05232702
24	Terminal board	42000100000202
25	Filter Board	30221000021
26	Main Board	300002060224

GUD100T/B-S

Exploded View




GUD100T/B-S

Spare Parts List

No.	Part Description	Part Code
1	Electric Box Assy	100002061280
2	Terminal Board	42018000551
3	Diversion Circle	10479400002
4	Water Tray Assy	000069060008
5	Fixed Mount 1(Evaporator)	0184940000701P
6	Evaporator Assy	011001061309
7	Liquid Level Switch	4502021601
8	Side Plate 1	01319400025
9	Body Installing Plate	01332701
10	Side Plate 3	01319400036
11	Base Plate Sub-Assy	02229400011
12	Seal plate Assy	01499400001
13	Side Plate 2	01319400026
14	Drainage Pipe Sub-Assy	26909400055
15	Water Pump	43138000058
16	Brushless DC Motor	15709400009
17	Filter	07415210
18	Connection Sheet Assy	01349400025
19	Remote Control	N/A
20	Temperature Sensor	390000453
21	Tube sensor	39000286
22	Drain Hose Sub-Assy	05339400001
23	Centrifugal Fan	10429400003
24	Filter Board	30221000021
25	Main Board	300002060224
26	Terminal board	42000100000202

GUD125T/B-S

Exploded View




GUD125T/B-S

Spare Parts List

No.	Part Description	Part Code
1	Electric Box Assy	100002061280
2	Terminal Board	42018000551
3	Terminal board	42000100000202
4	Filter Board	30221000021
5	Main Board	300002060224
6	Centrifugal Fan	10429400003
7	Diversion Circle	10479400002
8	Brushless DC Motor	15709400009
9	Corrugated Pipe	05029434
10	Evaporator Assy	011001061016
11	Base Plate Sub-Assy	02229400011
12	Side Plate 2	01319400026
13	Side Plate 3	01319400036
14	Side Plate 1	01319400025
15	Drainage Pipe Sub-Assy	26909400055
16	Body Installing Plate	01332701
17	Liquid Level Switch Sub-assy	45018000029
18	Water Pump	43138000058
19	Remote Control	N/A
20	Temperature Sensor	390000453
21	Tube sensor	39000286
22	Drain Hose Sub-Assy	05339400001

GUD140T/B-S

Exploded View




GUD140T/B-S

Spare Parts List

No.	Part Description	Part Code
1	Electric Box Assy	100002061280
2	Terminal Board	42018000551
3	Terminal board	42000100000202
4	Filter Board	30221000021
5	Main Board	300002060224
6	Centrifugal Fan	10429400003
7	Diversion Circle	10479400002
8	Brushless DC Motor	15709400009
9	Corrugated Pipe	05029434
10	Evaporator Assy	011001061016
11	Base Plate Sub-Assy	02229400011
12	Side Plate 2	01319400026
13	Side Plate 3	01319400036
14	Side Plate 1	01319400025
15	Drainage Pipe Sub-Assy	26909400055
16	Body Installing Plate	01332701
17	Liquid Level Switch Sub-assy	45018000029
18	Water Pump	43138000058
19	Remote Control	N/A
20	Temperature Sensor	390000453
21	Tube sensor	39000286
22	Drain Hose Sub-Assy	05339400001

TF06

Exploded View



TF06

Spare Parts List

No.	Part Description	Part Code
1	Front Grill Assy	000142000003
2	Front Panel	20000300010202
3	Left Axile Bush	10512037
4	Motor Box	26909460
5	Step Motor	15729401
6	Crank	10582070
7	Louver Motor Sub-assy	15409407
8	Corner Cover	200248000004
9	Corner Cover	200248000003
10	Foam	120000060167
11	Foam	120000000035
12	Foam	120000000036
13	Corner Cover	200248000002
14	Corner Cover	200248000001
15	Receiver Board	30261016
16	Display Box	26909455
17	Display Box Cover	26909454
18	Guide Louver	200004000038
19	Filter Sub-Assy	11729405
20	Front Grill	200226000002S
21	Fastener	200108000005

It is the policy of Gree Australia to introduce continuous product improvements.
Accordingly, specifications are subject to change without notice.
Please consult with your dealer to confirm the specifications of the model selected.

1800 473 346
greeac.com.au

