




# **INDOOR R32 U-MATCH UNDER CEILING**

## **SPARE PARTS LIST**

February 2023

# GUD50ZD/B-S

## Exploded View




**GUD50ZD/B-S**

## Spare Parts List

No.	Part Description	Part Code
1	Remote Control	N/A
2	Temperature Sensor	390001923
3	Ambient Temperature Sensor	3900012123
4	Drainage Pipe Sub-assy	05235434
5	Water Tray	200063000024
6	Swing Lever	10582009
7	Air Louver	20000700000101
8	Support	2690940007601
9	Right Side Plate	2690940007101
10	Installation Supporting Frame	01809402
11	Right Side Plate	26909400074
12	Axile Bush	10542704
13	Front Panel	20000300000101
14	Guide Louver	20000400004601
15	Evaporator Assy	011001061198
16	Rotating Shaft	26909430
17	Display Board	30294000009
18	Base Plate Assy	011007060037
19	Crankshaft	200023000001
20	Stepping Motor	1521240215
21	Electric Box Assy	100002003030
22	Main Board	300002060226
23	Terminal Board	42018000551
24	Terminal Board	42000100000204
25	Installation Supporting Frame	01809401
26	Left Side Plate	2690940007001
27	Clapboard Sub-Assy	017021000088
28	Propeller Housing(Lower)	200230000001
29	Rear Side Plate Sub-Assy	017051000046
30	Brushless DC Motor	15706000037
31	Centifugal Fan	103003000001
32	Propeller Housing(Upper)	200230000002
33	Filter Sub-Assy	111001000072
34	Top Cover	012148000046
35	Front Grill Sub-assy	20022600000401

# GUD71ZD/B-S

## Exploded View




**GUD71ZD/B-S**

## Spare Parts List

No.	Part Description	Part Code
1	Remote Control	N/A
2	Ambient Temperature Sensor	3900012123
3	Temperature Sensor	3900019204
4	Right Side Plate	2690940007101
5	Right Side Plate	26909400074
6	Installation Supporting Frame	01809402
7	Axile Bush	10542704
8	Evaporator Assy	011001061112
9	Rotating Shaft	26909430
10	Guide Louver	20000450042201
11	Crankshaft	200023000001
12	Stepping Motor	1521240215
13	Display Board	30294000009
14	Base Plate Assy	011007000038
15	Installation Supporting Frame	01809401
16	Left Side Plate	2690940007001
17	Main Board	300002060226
18	Terminal Board	42018000551
19	Terminal Board	42000100000204
20	Electric Box Assy	100002003030
21	Clapboard Sub-Assy	01249400018
22	Support Of Motor Bearing	01792408
23	O-Gasket of Bearing	76512404
24	Propeller Housing(Lower)	200230000001
25	Centifugal Fan	103003000001
26	Joint Slack	73018731
27	Brushless DC Motor	1570520000501
28	Roller Wheel	700004500433
29	Propeller Housing(Upper)	200230000002
30	Filter Sub-assy(Rear Side Plate)	111001000001
31	Rear Side Plate Sub Assy	017051000005
32	Swing Lever	10582009
33	Support	2690940007601
34	Air Louver	20000700000101
35	Water Tray Assy	000069060049
36	Top Cover	01269400012P01
37	Front Grill	2690940007201
38	Drainage Pipe Sub-assy	05235434

# GUD100ZD/B-S

## Exploded View




**GUD100ZD/B-S**

## Spare Parts List

No.	Part Description	Part Code
1	Remote Control	N/A
2	Temperature Sensor	3900019204
3	Ambient Temperature Sensor	3900012123
4	Drainage Pipe Sub-assy	05235434
5	Water Tray Assy	000069060049
6	Swing Lever	10582009
7	Air Louver	20000700000101
8	Support	2690940007601
9	Rotating Shaft	26909430
10	Right Side Plate	2690940007101
11	Installation Supporting Frame	01809402
12	Right Side Plate	26909400074
13	Axile Bush	10542704
14	Guide Louver	20000450042201
15	Evaporator Assy	011001061197
16	Display Board	30294000009
17	Crankshaft	200023000001
18	Stepping Motor	1521240215
19	Base Plate Assy	011007000038
20	Electric Box Assy	100002003030
21	Installation Supporting Frame	01809401
22	Main Board	300002060226
23	Terminal Board	42018000551
24	Terminal Board	42000100000204
25	Left Side Plate	2690940007001
26	Support Of Motor Bearing	01792408
27	O-Gasket of Bearing	76512404
28	Clapboard Assy	000075000040
29	Propeller Housing(Lower)	200230000001
30	Roller Wheel	700004500433
31	Filter Sub-assy(Rear Side Plate)	111001000001
32	Rear Side Plate Sub Assy	017051000005
33	Joint Slack	73018731
34	Brushless DC Motor	1570520000501
35	Centifugal Fan	103003000001
36	Propeller Housing(Upper)	200230000002
37	Front Grill Sub-Assy	2690940006601
38	Top Cover	01269400012P01

# GUD125ZD/B-S

## Exploded View






**GUD125ZD/B-S**

## Spare Parts List

No.	Part Description	Part Code
1	Remote Control	N/A
2	Tube sensor	3900020720G
3	Ambient Temperature Sensor	3900012123
4	Right Side Plate	2690940007101
5	Right Side Plate	26909400074
6	Installation Supporting Frame	01809402
7	Axile Bush	10542704
8	Evaporator Assy	011001061111
9	Rotating Shaft	26909430
10	Guide Louver	20000450042601
11	Crankshaft	200023000001
12	Stepping Motor	1521240215
13	Display Board	30294000009
14	Base Plate Assy	011007060032
15	Clapboard Sub-Assy	01249400019
16	Left Side Plate	2690940007001
17	Installation Supporting Frame	01809401
18	Main Board	300002060226
19	Terminal Board	42018000551
20	Terminal Board	42000100000204
21	Electric Box Assy	100002063110
22	Support Of Motor Bearing	01792408
23	O-Gasket of Bearing	76512404
24	Propeller Housing(Lower)	200230000001
25	Roller Wheel	700004000001
26	Joint Slack	73018731
27	Brushless DC Motor	15709400005
28	Centifugal Fan	103003000001
29	Propeller Housing(Upper)	200230000002
30	Rear Side Plate Sub-Assy	017051000006
31	Filter Sub-assy(Rear Side Plate)	111001000001
32	Drainage Pipe Sub-assy	05235434
33	Swing Lever	10582009
34	Air Louver	20000700000101
35	Support	2690940007601
36	Water Tray	200063000002
37	Top Cover	01269400013P01
38	Front Grill Sub-Assy	2690940006601

# GUD140ZD/B-S

## Exploded View



**GUD140ZD/B-S**

## Spare Parts List

No.	Part Description	Part Code
1	Remote Control	N/A
2	Tube sensor	3900020720G
3	Ambient Temperature Sensor	3900012123
4	Right Side Plate	2690940007101
5	Right Side Plate	26909400074
6	Installation Supporting Frame	01809402
7	Axile Bush	10542704
8	Evaporator Assy	011001061111
9	Rotating Shaft	26909430
10	Guide Louver	20000450042601
11	Crankshaft	200023000001
12	Stepping Motor	1521240215
13	Display Board	30294000009
14	Base Plate Assy	011007060032
15	Clapboard Sub-Assy	01249400019
16	Left Side Plate	2690940007001
17	Installation Supporting Frame	01809401
18	Main Board	300002060226
19	Terminal Board	42018000551
20	Terminal Board	42000100000204
21	Electric Box Assy	100002063110
22	Support Of Motor Bearing	01792408
23	O-Gasket of Bearing	76512404
24	Propeller Housing(Lower)	200230000001
25	Roller Wheel	700004000001
26	Joint Slack	73018731
27	Brushless DC Motor	15709400005
28	Centifugal Fan	103003000001
29	Propeller Housing(Upper)	200230000002
30	Rear Side Plate Sub-Assy	017051000006
31	Filter Sub-assy(Rear Side Plate)	111001000001
32	Drainage Pipe Sub-assy	05235434
33	Swing Lever	10582009
34	Air Louver	20000700000101
35	Support	2690940007601
36	Water Tray	200063000002
37	Top Cover	01269400013P01
38	Front Grill Sub-Assy	2690940006601

It is the policy of Gree Australia to introduce continuous product improvements.  
Accordingly, specifications are subject to change without notice.  
Please consult with your dealer to confirm the specifications of the model selected.

1800 473 346  
[greeac.com.au](http://greeac.com.au)

