



EARTHED SHIELD CABLES
THE HAN-L62 INTERFACE CABLE SUPPLIED IS A FOUR CORE AND EARTH CABLE. THE GREEN EARTH WIRE MUST BE CONNECTED TO EARTH (GROUND) AT THE MAIN BOARD END.

NOTE 1
THE OUTDOOR COIL SENSOR BULB SHOULD BE LOCATED IN A COPPER WELL SILVER SOLDERED TO A COIL RETURN BEND. WHEN ATTACHING THE SENSOR, USE A THERMAL CONDUCTING PASTE TO ENSURE GOOD HEAT TRANSFER. LOCATE THE SENSOR IN A POSITION APPROX. MID CIRCUIT OF ONE OF THE COIL CIRCUITS. WHENEVER REPLACING ANY HDC CONTROL ALWAYS FIT NEW SENSOR AS SUPPLIED. FOR FURTHER INFORMATION CONTACT HANWEST PTY LTD.

NOTE 2 - JP1
* FOR NORMAL OPERATION THE TEST JUMPER PINS MUST NOT BE SHORTENED.

NOTE 3 - "TEST" SWITCH
* TO INITIATE OR TERMINATE DEFROST.

NOTE 4
* SHOWN AS REVERSING VALVE ON IN HEAT MODE.

NOTE 5
* RELAY OPENS DURING DEFROST IN HEAT MODE.

LEGEND
RV - 4 WAY REVERSING VALVE
CR - COMPRESSOR RELAY
CF - CONDENSER FAN MOTOR

CD	SENSOR NOTE	31 JAN 2011
APP BY	DESCRIPTION	DATE

HANWEST PTY LTD
SPECIALISED COMPONENTS FOR AIR CONDITIONING & REFRIGERATION
ABN 92 431 001 201 ACN 003 452 551
94-98 JARDINE STREET FAIRY MEADOW NSW 2519
P:02 42835377 F: 0242835467 E:sales@hanwest.com.au

CONNECTION DIAGRAM FOR HAN-L62/PCB-132
MICROPROCESSOR CONTROLLER WITH
HDC-203 CONDENSER UNIT CONTROLLER.

DRAWN	CD	
CHKD	DS	
SCALE	NTS	
REV	1	
DATE	JANUARY 2012	
DWG. NO.	STD-L62-132-203	